

FIG.1




FIG. 2




FIG. 3

Timing chart for OSD data (MSM interface)





FIG.4



- \* SUB-MENU DISPLAY AREA COORDINATES ON LCD  
FONT SIZE  $(18 \times 19) \times 3 \text{ROW} = 57 \text{PIXEL} + \text{MARGIN } 3 \text{PIXEL} = 60 \text{PIXEL}$
- \* TV PICTURE DISPLAY AREA (IF FULL)  $\rightarrow 176 \times 220$  ALL USED

FIG.5




FIG.6




FIG.7




FIG.8







FIG. 9



\*  DIRECT ACCESS FUNCTION

\*  (RETURN TO UPPER MENU): **(CANCEL) Key**

FIG.10



FIG. 11A





FIG. 11B






FIG. 12B




FIG.13A




FIG.13B




FIG.13C